


LOCALISATION DES SUPPORTS ENTREE / SORTIE D'AGGLOMERATION

VILLALBE



VILLALBE			
Syst. coordonnées : Lambert 93			
		Coordonnées X	Coordonnées Y
1	EB10	642 418.249	6 232 355.058
	EB20	642 421.478	6 232 364.970
2	EB10	643 279.455	6 232 503.760
	EB20	643 281.743	6 232 508.165
3	EB10	643 674.526	6 232 489.767
	EB20	643 679.496	6 232 489.308
4	EB10	643 905.547	6 232 386.528
	EB20	643 902.690	6 232 386.846
5	EB10	644 043.959	6 232 796.367
	EB20	644 048.802	6 232 796.593

(Format A3)



1 / 6000